

GENIEMAT[®] FF LARGE FORMAT PANEL

Concrete Topping | Installation Guide

EQUIPMENT REQUIRED


- Table saw / circular saw
- Rubber mallet
- Staple gun
- Staples
- **GenieMat Tape ST3**
- Prybar
- 6 mil poly sheet
- 1/4" plywood (**GenieMat FF Large Format Panel Installation**)

GENERAL METHOD

GenieMat FF Large Format Panels are installed from one corner of the room diagonally to the opposite corner. Subfloor should be clean and prepped as specified by the finish flooring provider's specification. Steps 1-6 should be completed as each panel is installed (i.e. do not install the entire area before stapling the seams). As panels are being installed, place plywood on top in high traffic areas to prevent damaging the panels.


STEP 1

Determine overall dimensions of room (width and length). Determine start point of panels to avoid small cuts at perimeter.




STEP 2

Allow for perimeter gap by installing perimeter isolation strip (**GenieMat PMI12PF**) around all columns, walls and protrusions. Tape to the wall with **GenieMat Tape ST3** Note: **GenieMat PMI12PF** to extend above height of finished floor.




STEP 3

Install panels from one corner of the room diagonally to the opposite corner.



Do not directly hit the edge of the **GenieMat FF Large Format Panels** with a mallet or hammer. Use a wood block flush with the edge to distribute the load and protect the edges as the panels are hit into place.



For Your Project Specific Questions
T. 416.449.0049 | **E.** info@pliteq.com

© Pliteq Inc. 2025.

[®] Trademarks of Pliteq Inc. The information provided is accurate to the best of our knowledge at the time of issue. However, we reserve the right to make changes when necessary without further notification. Suggested application may need to be modified to conform with local building codes and conditions. We cannot accept responsibility for products that are not used, or installed, to our specifications. All listed dimensions are nominal.




GENIEMAT[®] FF LARGE FORMAT PANEL

Concrete Topping | Installation Guide


STEP 4

- i. Cut perimeter panels to size using table saw/circular saw.
- ii. If cut piece is small, isolator may need to be repositioned.




STEP 5

Install cut panels around perimeter to complete grid.




STEP 6

Staple tongue and groove in three places per seam.




STEP 7

Avoid walking on installed and stapled **GenieMat FF Large Format Panels**. Place plywood on top in high traffic areas to prevent damaging the panels.




STEP 8

Roll out 6 mil poly.



STEP 9

Staple the 6 mil poly to the **GenieMat PMI12PF**. Staple it 3 to 4 inches up the wall in order to cover perimeter gap.



For Your Project Specific Questions
 T. 416.449.0049 | E. info@pliteq.com

© Pliteq Inc. 2025.

®/™ Trademarks of Pliteq Inc. The information provided is accurate to the best of our knowledge at the time of issue. However, we reserve the right to make changes when necessary without further notification. Suggested application may need to be modified to conform with local building codes and conditions. We cannot accept responsibility for products that are not used, or installed, to our specifications. All listed dimensions are nominal.




GENIEMAT® FF LARGE FORMAT PANEL

Concrete Topping | Installation Guide

STEP 10

Tape the seams of the 6 mil poly with **GenieMat Tape ST3**.



CONTACT US

For Your Project Specific Questions
T. 416.449.0049 | E. info@pliteq.com

© Pliteq Inc. 2025.

®/™ Trademarks of Pliteq Inc. The information provided is accurate to the best of our knowledge at the time of issue. However, we reserve the right to make changes when necessary without further notification. Suggested application may need to be modified to conform with local building codes and conditions. We cannot accept responsibility for products that are not used, or installed, to our specifications. All listed dimensions are nominal.



www.pliteq.com