

GENIEMat® FF INSTALLATION GUIDE



Step 1: Sweep subfloor of all dust and debris and begin to roll out the perimeter isolation strip (PMI) along the base of all the walls and any protrusions through the subfloor.



Step 2: Begin to roll out **GenieMat® FF** layer(s) and stagger the seams in a brick like pattern.

Note: Install dimple side facing downward. When installing a multi layer system, roll out the next layer perpendicular to the layer beneath. The final layer will be the **GenieMat® FF** rolls with the built in poly sheet.



Step 3: Using **GenieMat Tape ST3**, tape all the seams to seal the **GenieMat® FF** system when a concrete topping is to be applied.

Note: Taping the seams is only necessary for the final layer of **GenieMat® FF** with the poly sheet when installing a multilayered system with a concrete topping.



Step 4: Pour concrete directly onto the **GenieMat® FF** system.

Note: Different types of topping such as **GenieBoard®** or plywood can be installed in lieu of concrete.

